

## Report Test

To protect the privacy of customers or suppliers of Salamander Jewelry.  
We erased their address from this document.

**LOT No :** 0264/2021

**Date :** 3 August 2021

### Determination of Sterilization Operation Specification

Item Detail	Specification	Setting	Result
Chamber Setting Temperature	40.0-55.5 °C	45.0 °C	
Vacuum pressure	40-60 kPa	60 kPa	
Vacuum Time	50-60 min	60 min	
<b>Humidification</b>			
Humidity	50.0-90.0%	20.2 %	
<b>Sterilization</b>			
Sterilization Temperature	40.0-55.5 °C	43.5 °C	
<b>Gas Injection</b>			
Final pressure	0-10 kPa	4 kPa	
Final temperature of vaporizer	40.0-55.5 °C	44.8 °C	
<b>Exposure</b>			
Temperature at start point of Exposure time period	40.0-55.5 °C	43.3 °C	
Temperature at finish point of Exposure time period	40.0-55.5 °C	46.0 °C	
Exposure Time	120-240 min	180 min	
<b>Exhaust</b>			
Exhaust Time	60-80 min	75 min	
First Vacuum pressure	0-2 kPa	1.5 kPa	
Second Vacuum pressure	0-2 kPa	1.5 kPa	
Third Vacuum pressure	0-2 kPa	1.5 kPa	
Fourth Vacuum pressure	0-2 kPa	1.5 kPa	
Fifth Vacuum pressure	0-2 kPa	1.5 kPa	
<b>Storage</b>			
Storage Time	≥ 48 hour	≥ 48 hour	
<b>Chemical Test</b>			
EO sterilization temperature 40-55°C, Time Sterilization by EO 3hours	Blue	Red	Pass
<b>Biological Test</b>			
EZ Test Biological Indicator	Green	Green	Pass

(.....*Jutha Liam.*.....)  
Mr. Jutha Liamukda  
Research and Development Engineer  
Salamander Jewelry Co., Ltd.

<p>END</p> <p>Air replacement:          Temperature: 44.9°C          Humidity: 58.4RH          Pressures: -1.5KPa          Sterilization time: 0Hour          Air replace rounds: 1          round time: 0min(s)          2021-4-21 16:45</p> <p>Air replacement:          Temperature: 44.9°C          Humidity: 59.3RH          Pressures: -1.5KPa          Sterilization time: 0Hour          Air replace rounds: 2          round time: 0min(s)          2021-4-21 16:25</p> <p>Air replacement:          Temperature: 44.9°C          Humidity: 62.4RH          Pressures: -1.5KPa          Sterilization time: 0Hour          Air replace rounds: 3          round time: 0min(s)          2021-4-21 16:4</p> <p>Air replacement:          Temperature: 44.9°C          Humidity: 66.4RH          Pressures: -1.5KPa          Sterilization time: 0Hour          Air replace rounds: 4          round time: 0min(s)          2021-4-21 15:44</p> <p>Air replacement:          Temperature: 48.0°C          Humidity: 75.1RH          Pressures: -1.5KPa          Sterilization time: 0Hour          Air replace rounds: 5          round time: 15min(s)          2021-4-21 15:24</p> <p>Sterilization:          Temperature: 45.6°C          Humidity: 80.9RH          Pressures: -0.0KPa          Sterilization time: 0Hour          Air replace rounds: 5          round time: 15min(s)          2021-4-21 15:18</p> <p>Sterilization:          Temperature: 43.3°C          Humidity: 80.0RH          Pressures: -0.5KPa          Sterilization time: 3Hour          Air replace rounds: 5          round time: 15min(s)          2021-4-21 12:20</p>	<p>Sterilization:          Temperature: 43.7°C          Humidity: 80.7RH          Pressures: -2.2KPa          Sterilization time: 3Hour          Air replace rounds: 5          round time: 15min(s)          2021-4-21 12:18</p> <p>Add EO gas          Temperature: 43.6°C          Humidity: 80.0RH          Pressures: -4.0KPa          Sterilization time: 3Hour          Air replace rounds: 5          round time: 15min(s)          2021-4-21 12:18</p> <p>Evacuation          Temperature: 44.8°C          Humidity: 71.4RH          Pressures: -0.0KPa          Sterilization time: 3Hour          Air replace rounds: 5          round time: 15min(s)          2021-4-21 12:12</p> <p>Keeping Temp          Temperature: 45.1°C          Humidity: 20.2RH          Pressures: -1.5KPa          Sterilization time: 3Hour          Air replace rounds: 5          round time: 15min(s)          2021-4-21 11:12</p> <p>Keep pressure qualified          Temperature: 44.5°C          Humidity: 20.2RH          Pressures: -59.2KPa          Sterilization time: 3Hour          Air replace rounds: 5          round time: 15min(s)          2021-4-21 11:11</p> <p>Evacuation          Temperature: 42.7°C          Humidity: 20.2RH          Pressures: -3.0KPa          Sterilization time: 3Hour          Air replace rounds: 5          round time: 15min(s)          2021-4-21 10:59</p> <p>Heating-up:          Temperature: 23.9°C          Humidity: 20.1RH          Pressures: -3.0KPa          Sterilization time: 3Hour          Air replace rounds: 5          round time: 15min(s)          2021-4-21 10:34</p> <p>Setting:          Temperature: 45.0°C          Humidity: 55.0RH          Pressures: -60.0KPa          Sterilization time: 3Hour          Air replace rounds: 5          round time: 15min(s)          2021-4-21 10:33</p>
---	---

LINE	Code	Description	LOT	Color	BOX	TOTAL
<b>2360017</b>						
4	THD-Z-BKCB-1.6-12.0-4	STERILE BLACK PVD COATED SURGICAL STEEL CIRCULAR BARBELL FOR THENDRO	LOT-0264			50
5	THD-Z-BL-1.6-18.0-5	STERILE SURGICAL STEEL BARBELL FOR THENDRO	LOT-0264			100
6	THD-Z-BL-1.6-8.0-4	STERILE SURGICAL STEEL BARBELL FOR THENDRO	LOT-0264			200
7	THD-Z-BN-1.6-14.0-4	STERILE SURGICAL STEEL CURVED BARBELL FOR THENDRO	LOT-0264			50
8	THD-Z-MCB-1.2-12.0-3	STERILE SURGICAL STEEL MICRO CIRCULAR BARBELL FOR THENDRO	LOT-0264			100
9	THD-Z-MLB-1.2-6.0-3	STERILIZED SURGICAL STEEL MICRO LABRET FOR THENDRO	LOT-0264			100
10	THD-Z-TBC-1.2-12.0-4	STERILE TITANIUM BALL CLOSURE RING FOR THENDRO	LOT-0264			150
11	THD-Z-TBC-1.6-12.0-4	STERILE TITANIUM BALL CLOSURE RING FOR THENDRO	LOT-0264			100
12	THD-Z-TBL-1.6-34.0-4	STERILE TITANIUM BARBELL FOR THENDRO	LOT-0264			50
14	THD-Z-TBL-1.6-38.0-4	STERILE TITANIUM BARBELL FOR THENDRO	LOT-0264			50
16	THD-Z-TLB-1.6-8.0-4	STERILE TITANIUM LABRET FOR THENDRO	LOT-0264			200
<b>2360336</b>						
5	PT-Z-TBL-1.6-38.0-5	STERILIZED TITANIUM BARBELL FOR PTIT ROC	LOT-0264			35
8	PT-Z-TJNO-0.8-6.5-2.35-CR	STERILE TITANIUM JEWELED CURVED NOSE STUD FOR PTIT ROC	LOT-0264	CR		644
10	PT-Z-TMBL-1.2-8.0-3-HP	STERILE TITANIUM MICRO BARBELL FOR PTIT ROC	LOT-0264			136
<b>2357986</b>						
2	PT-Z-TBCH-1.2-10.0-4	STERILE TITANIUM BALL CLOSURE RING WITH HEMA TITE BALL FOR PTIT ROC	LOT-0264			102
3	PT-Z-TBCH-1.6-12.0-4	STERILE TITANIUM BALL CLOSURE RING WITH HEMA TITE BALL FOR PTIT ROC	LOT-0264			51
6	PT-Z-TBL-1.6-20.0-5	STERILIZED TITANIUM BARBELL FOR PTIT ROC	LOT-0264			138
<b>2359599</b>						
1	TDI-Z-TBL-1.6-16.0-5	STERILE TITANIUM BARBELL FOR TDI	LOT-0264			200
4	TDI-Z-TINDAJD-1.6-1.5-4-CR	STERILE TITANIUM INTERNALLY THREADED DERMAL ANCHOR WITH JEWELED DISC FOR TDI	LOT-0264	CR		100
5	TDI-Z-TINDAJD-1.6-2.0-4-CR	STERILE TITANIUM INTERNALLY THREADED DERMAL ANCHOR WITH JEWELED DISC FOR TDI	LOT-0264	CR		100
<b>2360499</b>						
1	TDI-Z-BL-1.6-14.0-5	STERILE SURGICAL STEEL BARBELL FOR TDI	LOT-0264			200
2	TDI-Z-MBN-1.2-9.0-3	STERILE SURGICAL STEEL MICRO CURVED BARBELL FOR TDI	LOT-0264			100
<b>2360319</b>						
1	Z-TBL-1.6-22.0-5-HP	STERILE TITANIUM BARBELL	LOT-0264			10
<b>2359117</b>						
6	PT-Z-TCB-1.6-12.0-4	STERILE TITANIUM 90 DEGREE STAPLE BARBELL FOR PTIT ROC	LOT-0264			30
<b>2359806</b>						
1	Z-MLB-1.2-8.0-3	STERILE SURGICAL STEEL MICRO LABRET	LOT-0264			200
<b>2356782</b>						
12	PT-Z-XBNNJ-1.1-6-12.0-5/8-CR	STERILE BIOFLEX JEWELED NAVEL BANANA WITH SURGICAL STEEL BALL FOR PTIT ROC	LOT-0264	CR		50
<b>2358820</b>						
7	TDI-Z-TINMLBJ-1.2-10.0-2-CR	STERILE TITANIUM INTERNALLY THREADED JEWELED MICRO LABRET FOR TDI	LOT-0264	CR		300
<b>2350371</b>						
2	TDI-Z-TINBL-1.6-22.0-5	STERILE TITANIUM INTERNALLY THREADED BARBELL FOR TDI	LOT-0264			100
<b>2352538</b>						
15	PT-Z-TCB-1.6-10.0-4	STERILE TITANIUM 90 DEGREE STAPLE BARBELL FOR PTIT ROC	LOT-0264			102
<b>2359850</b>						
1	Z-GSNEEDLES-1.6-48.0	STERILIZED STAINLESS STEEL NEEDLE	LOT-0264			380
<b>2359878</b>						
3	TDI-Z-BNJ-OP-1.6-10.0-5/8-CR	STERILE SURGICAL STEEL CZECH CRYSTAL JEWELED NAVEL BANANA FOR TDI	LOT-0264	CR		100
<b>2354155</b>						
3	Z-FRTA-8.0-70.0	STERILE DISPOSABLE MULTI ANGLED RECEIVING TUBE 8.0MM	LOT-0264			1000
<b>152747</b>						
2	Z-BC-1.2-12.0-4	STERILE SURGICAL STEEL BCR	LOT-0264			100
5	Z-MBL-1.2-10.0-3	STERILE SURGICAL STEEL MICRO BARBELL	LOT-0264			100
6	Z-MCB-1.2-8.0-3	STERILE SURGICAL STEEL MICRO CIRCULAR BARBELL	LOT-0264			100
7	Z-TBL-1.6-38.0-5-HP	STERILE TITANIUM BARBELL	LOT-0264			100
<b>153118</b>						
35	Z-XINBLJS1-1.6-16.0-CL-CR	STERILE BIOFLEX PUSH FIT JEWELED NIPPLE BARBELL - ROUNDS	LOT-0264	CR		6
36	Z-XINBLJS1-1.6-18.0-CL-CR	STERILE BIOFLEX PUSH FIT JEWELED NIPPLE BARBELL - ROUNDS	LOT-0264	CR		7
<b>153039</b>						
2	Z-SES1-3-CR	STERILE SURGICAL STEEL ROUND PRONG SET JEWELED EAR STUDS PAIR	LOT-0264	CR		120
3	Z-SES1-4-CR	STERILE SURGICAL STEEL ROUND PRONG SET JEWELED EAR STUDS PAIR	LOT-0264	CR		30
<b>152671</b>						
1	Z-BL-1.6-10.0-5	STERILE SURGICAL STEEL BARBELL	LOT-0264			4
<b>152761</b>						
2	Z-PFIN-PIN-1.2-6.0-3B	STERILE SURGICAL STEEL THREADLESS LABRET PIN	LOT-0264			100

			153259			
1	Z-BL-1.6-44.0-4	STERILE SURGICAL STEEL BARBELL	LOT-0264		100	
2	Z-MBL-1.2-10.0-3	STERILE SURGICAL STEEL MICRO BARBELL	LOT-0264		400	
3	Z-MBL-1.2-12.0-3	STERILE SURGICAL STEEL MICRO BARBELL	LOT-0264		100	
4	Z-MBL-1.2-14.0-3	STERILE SURGICAL STEEL MICRO BARBELL	LOT-0264		100	
5	Z-MLB-1.2-6.0-3	STERILE SURGICAL STEEL MICRO LABRET	LOT-0264		200	
7	Z-TINDAJD-1.6-2.0-4-HP-CR	STERILE TITANIUM INTERNALLY THREADED DERMAL ANCHOR WITH JEWELLED DISC	LOT-0264	CR	25	
			152646			
4	Z-MBN-1.2-8.0-3	STERILE SURGICAL STEEL CURVED MICRO BARBELL	LOT-0264		200	
6	Z-MCB-1.2-12.0-3	STERILE SURGICAL STEEL MICRO CIRCULAR BARBELL	LOT-0264		150	
			153252			
54	Z-MLB-1.2-10.0-3	STERILE SURGICAL STEEL MICRO LABRET	LOT-0264		100	
			150336			
1	Z-XBNNU-1-1.6-12.0-5/8-CL-CR	BIOFLEX JEWELLED NAVEL BANANA WITH SURGICAL STEEL BALL	LOT-0264	CR	3	
			151228			
1	Z-XBNNU-1-1.6-12.0-5/8-CL-CR	BIOFLEX JEWELLED NAVEL BANANA WITH SURGICAL STEEL BALL	LOT-0264	CR	11	
			151410			
2	Z-XBNNU-1-1.6-12.0-5/8-CL-CR	BIOFLEX JEWELLED NAVEL BANANA WITH SURGICAL STEEL BALL	LOT-0264	CR	10	
			153446			
2	Z-XMBL-6-1.2-6.0-3-GR	STERILE BIOFLEX MICRO BARBELL WITH UV ACRYLIC BALLS	LOT-0264		10	
3	Z-XMBL-6-1.2-8.0-3-WH	STERILE BIOFLEX MICRO BARBELL WITH UV ACRYLIC BALLS	LOT-0264		10	
			153511			
2	Z-LB-1.6-5.0-4	STERILE SURGICAL STEEL LABRET	LOT-0264		1	
			153153			
6	Z-XBNIP10-1.6-16.0-4-CL-CR	STERILE BIOFLEX VERTICAL HOOD BANANAS WITH SURGICAL STEEL CHARMS - CAN BE CUT	LOT-0264	CR	1	
7	Z-XBNIP1-1.6-16.0-4-CL-AM	STERILE BIOFLEX VERTICAL HOOD BANANAS WITH SURGICAL STEEL CHARMS - CAN BE CUT	LOT-0264	AM	1	
8	Z-XBNIP1-1.6-16.0-4-CL-CR	STERILE BIOFLEX VERTICAL HOOD BANANAS WITH SURGICAL STEEL CHARMS - CAN BE CUT	LOT-0264	CR	1	
			152889			
11	Z-LJNO-1.0-6.5-2.35-CR	STERILE SURGICAL STEEL SWAROVSKI CRYSTAL JEWELLED LARGE LEFT CURVE NOSE STUD	LOT-0264	CR	3	
			153117			
1	Z-TBL-1.6-16.0-5-HP	STERILE TITANIUM BARBELL	LOT-0264		35	
4	Z-TINMJA004-1.2-HP-CR	STERILE TITANIUM MICRO JEWELLED ATTACHMENT FOR 1.2MM INTERNALLY THREADED PINS	LOT-0264	CR	15	
5	Z-TJNO-0.8-6.5-2.35-HP-CR	STERILE TITANIUM SWAROVSKI CRYSTAL JEWELLED CURVED NOSE STUD	LOT-0264	CR	35	
6	Z-TMB-1.2-3-HP	STERILE TITANIUM MICRO BALL	LOT-0264		20	
7	Z-TMB-1.2-4-HP	STERILE TITANIUM MICRO BALL	LOT-0264		25	
9	Z-TMBL-1.2-14.0-3-HP	STERILE TITANIUM MICRO BARBELL	LOT-0264		30	
11	Z-TMBLJ-1.2-8.0-3-HP-CR	STERILE TITANIUM JEWELLED MICRO BARBELL	LOT-0264	CR	5	
14	Z-TNO-0.8-6.5-2-HP	STERILE TITANIUM CURVED BALL NOSE STUD	LOT-0264		40	
15	Z-XINBLJS1-1.6-18.0-CL-CR	STERILE BIOFLEX PUSH FIT JEWELLED NIPPLE BARBELL - ROUNDS	LOT-0264	CR	1	
18	Z-ZGMB-1.2-4	STERILE ZIRCON GOLD PVD COATED SURGICAL STEEL MICRO BALL	LOT-0264		20	
			152458			
5	Z-MBN-1.2-8.0-3	STERILE SURGICAL STEEL CURVED MICRO BARBELL	LOT-0264		200	
			152414			
9	Z-MCB-1.2-12.0-3	STERILE SURGICAL STEEL MICRO CIRCULAR BARBELL	LOT-0264		100	
			153050			
9	Z-XBL-1-1.6-18.0-5-CL	STERILE BIOFLEX BARBELL WITH STEEL BALLS	LOT-0264		20	
			153118			
24	Z-TBL-1.6-24.0-5-HP	STERILE TITANIUM BARBELL	LOT-0264		6	
25	Z-TBN-1.6-10.0-4-HP	STERILE TITANIUM CURVED BARBELL	LOT-0264		10	
27	Z-TBNN-1.6-10.0-5/6-HP	STERILE TITANIUM NAVEL BANANA	LOT-0264		10	
28	Z-TMBL-1.2-16.0-4-HP	STERILE TITANIUM MICRO BARBELL	LOT-0264		40	
29	Z-TMBL-1.2-18.0-4-HP	STERILE TITANIUM MICRO BARBELL	LOT-0264		30	
30	Z-TMBL-1.2-19.0-4-HP	STERILE TITANIUM MICRO BARBELL	LOT-0264		20	
31	Z-TMBL-1.2-7.0-3-HP	STERILE TITANIUM MICRO BARBELL	LOT-0264		15	
33	Z-TMBN-1.2-7.0-3-HP	STERILE TITANIUM CURVED MICRO BARBELL	LOT-0264		13	
34	Z-TNOD-0.8-6.5-2-HP	STERILE TITANIUM CURVED DISC NOSE STUD	LOT-0264		15	

153220						
1	Z-GPSCJNO3-0.8-6.5-2.5-CR	STERILE GOLD PVD COATED SURGICAL STEEL CURVED PRONG SET 2.5MM JEWELLED NOSE STUD	LOT-0264	CR		5
3	Z-LBSC115-1.6-6.0-CR	STERILE SURGICAL STEEL SWAROVSKI CRYSTAL JEWELLED LABRET - FLOWER	LOT-0264	CR		1
4	Z-MBLSJ6-1.0-8.0-1.8-CR	STERILE SURGICAL STEEL CARTILAGE AND TRAGUS JEWELLED MICRO STUD	LOT-0264	CR		2
5	Z-MLBSC98-1.2-8.0-AB	STERILE SURGICAL STEEL MICRO LABRET WITH JEWELLED ATTACHMENT - 5 JEWELS	LOT-0264	AB		2
7	Z-SCNO113-0.8-6.5	STERILE SURGICAL STEEL CURVED NOSE STUD	LOT-0264			2
153012						
1	Z-MBLSSC408-1.2-6.0-3-CR	STERILE SURGICAL STEEL JEWELLED TRAGUS MICRO BARBELL	LOT-0264	CR		6
2	Z-RNJNO-0.8-6.5-2.35-CR	STERILE RAINBOW PVD COATED SURGICAL STEEL SWAROVSKI CRYSTAL JEWELLED CURVED NOSE STUD	LOT-0264	CR		6
3	Z-SCSH062-0.8-8.0-CR	STERILE SURGICAL STEEL JEWELLED MULTI PURPOSE CLICKER	LOT-0264	CR		2
4	Z-TINLB-1.6-8.0-2.5-HP	STERILE TITANIUM INTERNALLY THREADED LABRET	LOT-0264			10
5	Z-TINMLBJD-1.2-8.0-3-HP-CR	STERILE TITANIUM INTERNALLY THREADED JEWELLED DISC MICRO LABRET	LOT-0264	CR		20
150646						
1	Z-TNO-1.0-6.5-2-HP	STERILE TITANIUM CURVED BALL NOSE STUD	LOT-0264			10
151569						
4	Z-TCB-1.6-10.0-3-HP	STERILE TITANIUM CIRCULAR BARBELL	LOT-0264			20
<b>TOTAL</b>						<b>8112</b>