

Report Test

To protect the privacy of customers or suppliers of Salamander Jewelry.
We erased their address from this document.

LOT No : 0271/2021
Date : 23 August 2021

Determination of Sterilization Operation Specification

Item Detail	Specification	Setting	Result
Chamber Setting Temperature	40.0-55.5 °C	45.0 °C	
Vacuum pressure	40-60 kPa	60 kPa	
Vacuum Time	50-60 min	60 min	
Humidification			
Humidity	50.0-90.0%	20.2 %	
Sterilization			
Sterilization Temperature	40.0-55.5 °C	43.5 °C	
Gas Injection			
Final pressure	0-10 kPa	4 kPa	
Final temperature of vaporizer	40.0-55.5 °C	44.8 °C	
Exposure			
Temperature at start point of Exposure time period	40.0-55.5 °C	43.3 °C	
Temperature at finish point of Exposure time period	40.0-55.5 °C	46.0 °C	
Exposure Time	120-240 min	180 min	
Exhaust			
Exhaust Time	60-80 min	75 min	
First Vacuum pressure	0-2 kPa	1.5 kPa	
Second Vacuum pressure	0-2 kPa	1.5 kPa	
Third Vacuum pressure	0-2 kPa	1.5 kPa	
Fourth Vacuum pressure	0-2 kPa	1.5 kPa	
Fifth Vacuum pressure	0-2 kPa	1.5 kPa	
Storage			
Storage Time	≥ 48 hour	≥ 48 hour	
Chemical Test			
EO sterilization temperature 40-55°C, Time Sterilization by EO 3hours	Blue	Red	Pass
Biological Test			
EZ Test Biological Indicator	Green	Green	Pass

(*Jutha Liam*)
Mr. Jutha Liammukda
Research and Development Engineer
Salamander Jewelry Co., Ltd.

Air replacement:
Temperature: 45.5°C
Humidity: 58.3RH
Pressures: -1.5KPa
Sterilization time: 0Hour
Air replace rounds: 1
round time: 0min(s)
2021-8-26 16:10

Air replacement:
Temperature: 46.2°C
Humidity: 61.6RH
Pressures: -1.5KPa
Sterilization time: 0Hour
Air replace rounds: 2
round time: 0min(s)
2021-8-26 17:50

Air replacement:
Temperature: 45.6°C
Humidity: 64.3RH
Pressures: -1.5KPa
Sterilization time: 0Hour
Air replace rounds: 3
round time: 0min(s)
2021-8-26 17:30

Air replacement:
Temperature: 46.1°C
Humidity: 68.1RH
Pressures: -1.5KPa
Sterilization time: 0Hour
Air replace rounds: 4
round time: 0min(s)
2021-8-26 17:9

Air replacement:
Temperature: 45.3°C
Humidity: 79.0RH
Pressures: -1.5KPa
Sterilization time: 0Hour
Air replace rounds: 5
round time: 15min(s)
2021-8-26 16:49

Sterilization:
Temperature: 45.8°C
Humidity: 60.9RH
Pressures: -0.0KPa
Sterilization time: 0Hour
Air replace rounds: 5
round time: 15min(s)
2021-8-26 16:44

Sterilization:
Temperature: 43.4°C
Humidity: 77.7RH
Pressures: -4.7KPa
Sterilization time: 3Hour
Air replace rounds: 5
round time: 15min(s)
2021-8-26 13:45

Sterilization:
Temperature: 43.5°C
Humidity: 68.5RH
Pressures: -4.1KPa
Sterilization time: 3Hour
Air replace rounds: 5
round time: 15min(s)
2021-8-26 13:43

Add EO gas
Temperature: 43.6°C
Humidity: 70.3RH
Pressures: -4.0KPa
Sterilization time: 3Hour
Air replace rounds: 5
round time: 15min(s)
2021-8-26 13:43

Evacuation
Temperature: 44.5°C
Humidity: 66.2RH
Pressures: -0.0KPa
Sterilization time: 3Hour
Air replace rounds: 5
round time: 15min(s)
2021-8-26 13:38

Keeping Temp
Temperature: 44.9°C
Humidity: 20.2RH
Pressures: -1.5KPa
Sterilization time: 3Hour
Air replace rounds: 5
round time: 15min(s)
2021-8-26 12:38

Keep pressure qualified
Temperature: 44.1°C
Humidity: 20.1RH
Pressures: -59.2KPa
Sterilization time: 3Hour
Air replace rounds: 5
round time: 15min(s)
2021-8-26 12:36

Evacuation
Temperature: 42.5°C
Humidity: 20.1RH
Pressures: -3.0KPa
Sterilization time: 3Hour
Air replace rounds: 5
round time: 15min(s)
2021-8-26 12:25

Heating-up:
Temperature: 24.4°C
Humidity: 20.1RH
Pressures: -3.0KPa
Sterilization time: 3Hour
Air replace rounds: 5
round time: 15min(s)
2021-8-26 11:58

Setting:
Temperature: 45.0°C
Humidity: 55.0RH
Pressures: -60.0KPa
Sterilization time: 3Hour
Air replace rounds: 5
round time: 15min(s)



SALAMANDER
jewelry

Salamander Jewelry Co., Ltd.

128/1 Moo 7, Soi Wat Nakhon Chuenchum, Phutthamonthon Sai 4 Rd.
Tambon Krathumlom, Amphur Sampran, Nakhon Pathom 73220, Thailand.
Tel: 66-2814-4455 | Fax: 66-2-814-3300 | Email: info@body-piercing.com
Website: www.body-piercing.com

LINE	Code	Description	LOT	Color	BOX	TOTAL
2361679						
3	QL-Z-BKBN-1.6-12.0-5	STERILE BLACK PVD SURGICAL STEEL CURVED BARBELL FOR QUILLIAN	LOT-0271			50
6	QL-Z-BKJMB-1.2-3-CR	STERILE BLACK PVD COATED SURGICAL STEEL SWAROVSKI CRYSTAL JEWELED MICRO BALL FOR QUILLIAN NO CARD	LOT-0271	CR		50
16	QL-Z-BNDJ-1.6-14.0-5/8-CR	STERILE SURGICAL STEEL DOUBLE JEWELED NAVEL BANANA FOR QUILLIAN NO CARD	LOT-0271	CR		20
20	QL-Z-JB-1.6-5-CR	STERILE SURGICAL STEEL SWAROVSKI CRYSTAL JEWELED BALL FOR QUILLIAN NO CARD	LOT-0271	CR		50
33	QL-Z-ZGBL-1.6-12.0-4	STERILE ZIRCON GOLD PVD COATED SURGICAL STEEL BARBELL	LOT-0271			30
2359117						
11	PT-Z-TMLBJ-1.2-10.0-3-CR	STERILE TITANIUM MICRO LABRET WITH JEWELED BALL FOR PTIT ROC	LOT-0271	CR		128
19	PT-Z-TMLBJ-1.2-8.0-3-CR	STERILE TITANIUM MICRO LABRET WITH JEWELED BALL FOR PTIT ROC	LOT-0271	CR		109
2364126						
1	TDI-Z-MLB-1.2-10.0-2.5	STERILIZED SURGICAL STEEL MICRO LABRET FOR TDI	LOT-0271			200
3	TDI-Z-MLB-1.2-8.0-3	STERILIZED SURGICAL STEEL MICRO LABRET FOR TDI	LOT-0271			200
2350371						
3	TDI-Z-TINBL-1.6-32.0-5	STERILE TITANIUM INTERNALLY THREADED BARBELL FOR TDI	LOT-0271			50
2362330						
35	TDI-Z-TMLBJ-OP-1.2-6.0-3-CR	STERILE TITANIUM MICRO LABRET WITH JEWELED BALL FOR TDI	LOT-0271	CR		100
2361569						
8	TDI-Z-MCB-1.2-8.0-3	STERILE SURGICAL STEEL MICRO CIRCULAR BARBELL FOR TDI	LOT-0271			200
2363995						
1	Z-GSNEEDLES-1.2-48.0	STERILIZED STAINLESS STEEL NEEDLE	LOT-0271			400
2357551						
1	Z-XAJNO-1.0-6.0-2-CL-CR	STERILE ANTIMICROBIAL BIOFLEX JEWELED CURVED NOSE STUD	LOT-0271	CR		100
2364586						
7	TDI-Z-MLB-1.2-12.0-3	STERILIZED SURGICAL STEEL MICRO LABRET FOR TDI	LOT-0271			200
2336026						
11	MH-Z-BCS-1.6-7.0	STERILE SURGICAL STEEL SMOOTH SEGMENT RING FOR ERAORA CO	LOT-0271			50
2359599						
7	TDI-Z-TMBN-1.2-7.0-3	STERILE TITANIUM MICRO CURVED BARBELL FOR TDI	LOT-0271			100
2352538						
24	PT-Z-TMLB-1.2-10.0-3	STERILE TITANIUM MICRO LABRET FOR PTIT ROC	LOT-0271			417
2363233						
1	Z-TBL-1.6-22.0-5-HP	STERILE TITANIUM BARBELL	LOT-0271			10
2363254						
1	QL-S1-Z-JB-1.6-4-CR	SET OF STERILE SURGICAL STEEL SWAROVSKI CRYSTAL JEWELED BALL	LOT-0271			15
150646						
2	Z-BNDJ-1.6-12.0-4/8-CR	STERILE SURGICAL STEEL DOUBLE SWAROVSKI CRYSTALS JEWELED NAVEL BANANA	LOT-0271	CR		30
6	Z-INMBN-1.2-8.0-3	STERILE SURGICAL STEEL INTERNALLY THREADED CURVED MICRO BARBELL	LOT-0271			10
152166						
2	Z-BNJ-1.6-12.0-5/8-CR	STERILE SURGICAL STEEL JEWELED NAVEL BANANA	LOT-0271	CR		100
153532						
4	Z-MCB-1.2-8.0-3	STERILE SURGICAL STEEL MICRO CIRCULAR BARBELL	LOT-0271			20
153934						
2	Z-MCB-1.2-8.0-3	STERILE SURGICAL STEEL MICRO CIRCULAR BARBELL	LOT-0271			5
154584						
1	Z-BL-1.6-14.0-5	STERILE SURGICAL STEEL BARBELL	LOT-0271			150
2	Z-BL-1.6-38.0-4	STERILE SURGICAL STEEL BARBELL	LOT-0271			150
154517						
2	Z-STN5-12.0-CL	STERILE SILICONE FLARED TUNNEL	LOT-0271			2
154677						
1	Z-ININP-1.6-50.0	STERILE SURGICAL STEEL INTERNALLY THREADED INSERTION PINS	LOT-0271			2
153527						
5	Z-TBL-1.6-19.0-3-HP	STERILE TITANIUM BARBELL	LOT-0271			2
153314						
4	Z-TBL-1.6-19.0-3-HP	STERILE TITANIUM BARBELL	LOT-0271			15
154678						
3	Z-INCB-2.0-10.0-4	STERILE SURGICAL STEEL INTERNALLY THREADED CIRCULAR BARBELL	LOT-0271			2
4	Z-INCB-2.0-10.0-5	STERILE SURGICAL STEEL INTERNALLY THREADED CIRCULAR BARBELL	LOT-0271			4
149744						
1	Z-COBC-1.2-10.0	STERILE SURGICAL STEEL SEAMLESS RING	LOT-0271			10
149497						
1	Z-BNJ-1.6-12.0-5/8-CR	STERILE SURGICAL STEEL JEWELED NAVEL BANANA	LOT-0271	CR		7
149999						
63	Z-SC85-1.6	STERILE SURGICAL STEEL ATTACHMENT FOR 1.6 MM THREADED PINS - GUN	LOT-0271			9
154476						
1	Z-JNO-0.8-6.5-1.8-AB	STERILE SURGICAL STEEL SWAROVSKI CRYSTAL JEWELED CURVED NOSE STUD	LOT-0271	AB		1
154467						
1	Z-XINLB-PINS-1.2-8.0-4B-CL	STERILE BIOFLEX INTERNAL LABRET PIN	LOT-0271			2
154625						
2	Z-MBL-1.2-12.0-3	STERILE SURGICAL STEEL MICRO BARBELL	LOT-0271			300
148311						
1	Z-BL-1.6-44.0-5	STERILE SURGICAL STEEL BARBELL	LOT-0271			10
2	Z-BNJ-1.6-10.0-5/8-CR	STERILE SURGICAL STEEL JEWELED NAVEL BANANA	LOT-0271	CR		2
153118						
32	Z-TMLBJ-1.2-8.0-3-HP-CR	STERILE TITANIUM JEWELED MICRO BARBELL	LOT-0271	CR		35
33	Z-TMBN-1.2-7.0-3-HP	STERILE TITANIUM CURVED MICRO BARBELL	LOT-0271			3
150281						
8	Z-BL1DI-1.6-14.0-5	STERILE SURGICAL STEEL BARBELL WITH ONE DICE	LOT-0271			3
150172						
12	Z-XBL-1.1-6-22.0-5-CL	STERILE BIOFLEX BARBELL WITH STEEL BALLS	LOT-0271			20
148309						
6	Z-TJNO-1.0-6.5-2.35-HP-CR	STERILE TITANIUM SWAROVSKI CRYSTAL JEWELED CURVED NOSE STUD	LOT-0271	CR		4
147846						
4	Z-BNJ-1.6-10.0-5/8-CR	STERILE SURGICAL STEEL JEWELED NAVEL BANANA	LOT-0271	CR		8
151570						
3	Z-TJNO-1.0-6.5-2.35-HP-CR	STERILE TITANIUM SWAROVSKI CRYSTAL JEWELED CURVED NOSE STUD	LOT-0271	CR		8

			153777			
2	Z-MCB-1.2-10.0-3	STERILE SURGICAL STEEL MICRO CIRCULAR BARBELL	LOT-0271			300
			147830			
1	Z-TMLB-1.2-10.0-3-HP	STERILE TITANIUM MICRO LABRET	LOT-0271			24
			147828			
1	Z-TMLB-1.2-10.0-3-HP	STERILE TITANIUM MICRO LABRET	LOT-0271			1
			154594			
2	Z-INSCP275-1.2	STERILE SURGICAL STEEL MICRO ATTACHMENT FOR 1.2MM INTERNALLY THREADED PINS - WEB	LOT-0271			15
			154595			
7	Z-INSCP275-1.2	STERILE SURGICAL STEEL MICRO ATTACHMENT FOR 1.2MM INTERNALLY THREADED PINS - WEB	LOT-0271			3
			154607			
1	Z-XBCS-1.2-8.0-CL	STERILE BIOFLEX SEGMENT RING	LOT-0271			1
2	Z-XBCS-1.2-8.0-GD	STERILE BIOFLEX SEGMENT RING	LOT-0271			1
			154695			
1	Z-INMLBSJ1-1.2-10.0-4-CR	STERILE SURGICAL STEEL INTERNALLY THREADED ROUND PRONG SET JEWELED MICRO LABRET	LOT-0271	CR		27
2	Z-INMLBSJ1-1.2-7.0-4-CR	STERILE SURGICAL STEEL INTERNALLY THREADED ROUND PRONG SET JEWELED MICRO LABRET	LOT-0271	CR		8
			154696			
1	Z-INMLBSJ1-1.2-10.0-4-CR	STERILE SURGICAL STEEL INTERNALLY THREADED ROUND PRONG SET JEWELED MICRO LABRET	LOT-0271	CR		3
			154649			
72	Z-SCSH003-1.2-10.0	STERILE SURGICAL STEEL MULTI PURPOSE CLICKER - PLAIN	LOT-0271			3
73	Z-SCSH003-1.2-8.0	STERILE SURGICAL STEEL MULTI PURPOSE CLICKER - PLAIN	LOT-0271			3
			154230			
12	Z-SCSH023-1.2-6.0-CR	STERILE SURGICAL STEEL CRYSTALLINE JEWELED MULTI PURPOSE CLICKER	LOT-0271	CR		1
13	Z-SCSH023-1.2-10.0-CR	STERILE SURGICAL STEEL CRYSTALLINE JEWELED MULTI PURPOSE CLICKER	LOT-0271	CR		3
19	Z-MBLSC421-1.2-6.0-3-CR	STERILE SURGICAL STEEL JEWELED TRAGUS MICRO BARBELLS CHAIN LINKED - BOW	LOT-0271	CR		2
		TOTAL				3788